

Pipe Outside Diameter Guide

Nominal Pipe Size (Inches)	1/2	3/4	1	1 1/4	1 1/2	2	2 1/2	3	4	5	6	8	10	12	14	15	16	18	20	24	30
, , , , , , , , , , , , , , , , , , ,							2.63														
Steel Pipe Schedule 40	0.84	1.05	1.32	1.66	1.90	2.38	2.88	3.50	4.50	5.56	6.63	8.63	10.75	12.75	14.00		16.00	18.00	20.00	24.00	30.00
Plastic Pipe (P.V.C.) STD.			1.32		1.90	2.38	2.88	3.50	4.50		6.63	8.63	10.75	12.75							
Plastic Pipe (P.V.C.) C.I. Size									4.80		6.90	9.05	11.10	13.20							
PVC Sewer Pipe									4.22	5.64	6.28	8.40	10.50	12.50		15.30		18.70		24.80	
Polyethylene Pipe I.P.S.*		1.05	1.32	1.66	1.90	2.38		3.50	4.50	5.56	6.63	8.63	10.75	12.75	14.00		16.00	18.00	20.00	24.00	30.00
Polyethylene Pipe D.I. Size									4.80		6.90	9.05	11.10	13.20			17.40	19.50	21.60	25.80	
Plastic Irrigation Pipe (PIP)									4.13		6.14	8.16	10.20	12.24		15.30		18.70		24.80	

^{*}P.E. Tubing can be C.T.S.

Cast Iron Pine

Cast Iron Fipe																					
Nominal Pipe Size (Inches)	1/2	3/4	1	1 1/4	1 1/2	2	2 1/2	3	4	5	6	8	10	12	14	15	16	18	20	24	30
Class 100-250 AVWVA Centrifugally Cast								3.96	4.80		6.90	9.05	11.10	13.20	15.30		17.40	19.50	21.60	25.80	32.00
Class A AWWA Pit Cast						2.50		3.80	4.80		6.90	9.05	11.10	13.20	15.30		17.40	19.50	21.60	25.80	31.74
Class B AWWA Pit Cast								3.96	5.00		7.10	9.05	11.10	13.20	15.30		17.40	19.50	21.60	25.80	32.00
Class C AWWA Pit Cast								3.96	5.00		7.10	9.30	11.40	13.50	15.65		17.80	19.92	22.06	26.32	32.40
Class D AWWA Pit Cast								3.96	5.00		7.10	9.30	11.40	13.50	15.65		17.80	19.92	22.06	26.32	32.74
Soil Pipe						2.30		3.30	4.30	5.30	6.30	8.40	10.50	12.50		15.62					

Asbestos-Cement Pipe Class 100

Nominal Pipe Size (Inches)	1/2	3/4	1	1 1/4	1 1/2	2	2 1/2	3	4	5	6	8	10	12	14	15	16	18	20	24	30
Machined End								3.74	4.64		6.91	9.11	11.24*	13.44*	15.07		17.15	19.90	22.12	26.48	33.12
Fluid-Tite Rough Barrel								3.93	5.05		7.16	9.32	11.46	13.70	15.36		17.50				
Flintite Rough Barrel								3.94	4.90				11.30				17.60				
Ring-Tite Rough Barrel								3.95	4.92		7.19	9.39	11.47	13.74	15.51		17.65	20.44	22.68	27.12	33.80
Permaflex Rough Barrel									4.84		7.15	9.35	11.47	13.74	15.55		17.55				
Minimum Standard Rough Barrel									4.79		7.05	9.22	11.25	13.37	15.36		17.50	20 44	22 50	27.17	
Maximum Standard Rough Barrel									5.26		7.40	9.57	11.77	14.04	15.80		17.94	20.44	22.50	21.11	

Asbestos-Cement Pipe Class 150

Nominal Pipe Size (Inches)	1/2	3/4	1	1 1/4 1	1/2	2	2 1/2	3	4	5	6	8	10	12	14	15	16	18	20	24	30
Machined End								3.84	4.81		6.91	9.11	11.66	13.92	16.22		18.46	20.94	23.28	27.96	35.00
Fluid-Tite Rough Barrel								4.03	5.14					14.11			18.65				
Flintite Rough Barrel								4.04	5.01					14.14			18.72				
Ring-Tite Rough Barrel								4.13	5.07					14.18			18.72	21.30	23.64	28.32	35.42
Permaflex Rough Barrel									5.00		7.20	9.40	11.92	14.20	16.50		18.75				
Minimum Standard Rough Barrel									4.97					14.08			18.62	21 20	23 54	28.22	
Maximum Standard Rough Barrel									5.32		7.37	9.62	12.12	14.38	16.73		18.97	21.20	25.54	20.22	

Asbestos-Cement Pipe Class 200

Nominal Pipe Size (Inches)	1/2	3/4	1	1 1/4	1 1/2	2	2 1/2	3	4	5	6	8	10	12	14	15	16	18	20	24	30
Machined End								3.84	4.81		6.91	9.11	11.66	13.92	16.22		18.46	22.18	24.66	29.62	37.06
Fluid-Tite Rough Barrel								4.18	5.32		7.36	9.46	11.88	14.11	16.44		18.74				
Flintite Rough Barrel								4.17	5.32		7.26	9.44	11.88	14.14	16.53		18.84				
Ring-Tite Rough Barrel								4.17	5.33		7.32	9.50	11.92	14.18	16.55		18.90	22.54	25.02	29.98	37.48
Permaflex Rough Barrel									5.32		7.26	9.50	11.95	14.20	16.55		18.90				
Minimum Standard Rough Barrel									5.22		7.26	9.39	11.77	14.03	16.44		18.74				
Maximum Standard Rough Barrel									5.57		7.60	9.79	12.12	14.38	16.88		19.19				

^{*}Flintite M.E. is 10.89 for 10" and 12.99 for 12" sizes.

This Pipe O.D. Guide is based on the latest pipe standards and information supplied by pipe manufacturers.

Due to occasional changes in outside diameters by pipe manufacturers, the pipe O.D. or circumference should always be checked and furnished when ordering fittings.

To order these and other Smith-Blair products, contact your local Smith-Blair distributor.











973

Smith-Blair, Inc. Phone: 870-773-5127 • 800-643-9705 Fax: 870-773-5212 • 800-648-6792 www.smith-blair.com

Distributor:

111 Cam-Lock 136 Bell-Lock Joint Restraint Joint Restraint

226 Full-Circle **Repair Clamp**

315 Service Saddle

Coupling

Dismantling Joint